EU SCAN 84

# EU - ASSEMBLY AND INSTRUCTIONS MANUAL

# SCAN 84



SCAN®

ASSEMBLY AND INSTRUCTIONS MANUAL SCAN 84

EU SCAN 84

# CONGRATULATIONS ON YOUR NEW SCAN WOOD-BURNING STOVE

You have purchased a product by one of Europe's leading manufacturers of wood-burning stoves, and we are sure that you will have years of pleasure from your purchase.

To make the best possible use of your stove, it is important that you follow our advice and instructions. Read through this Assembly and Instruction Manual carefully before you start to assemble your stove.

SCAN 84
MODERN



SCAN 84
MODERN MAXI



# TABLE OF CONTENTS


## TECHNICAL DATA 4

Installation 4
Safety 4
Technical data 6
Type plate 8
Product registration number 8
Dimension sketch 9
Minimum distances 10

## ASSEMBLY 12

Tools needed for mounting of the stove 12
Loose parts 12
Additional accessories 12
Disposal of packaging 12
Room requirements 12
Fresh air intake 12
Closed combustion system 13
Existing chimney and pre-fabricated element chimney 13
Connection between stove and steel chimney 13
Requirements for chimney 14
Requirements for insulated chimney 14
Safety distance 14
Removal of packaging 15
Removal of transport protection 16
Height adjustment of stove 17
Fitting the flue connection piece 18
Soapstone top 20
Rotating base 20
Handle 21
Glass top 21
Heat-storage system 22
Load-bearing foundation 23
Floor plate 23

## INSTRUCTIONS FOR USE 24

CB-technology (Clean Burn) 24
Primary air 24
Secondary air 24
Baffle plates 24
Ash container 24
Handle for riddling grate 25

## INSTRUCTIONS FOR HEATING 26

Environmentally-friendly firing 26
Lighting 26
Continuous operation 27
Warning about over-firing 27
Using the stove in various weather conditions 27
Firing in the spring or autumn 27
The function of the chimney 27
Chimney fire 28
General notes 28

## HANDLING OF THE FUEL 29

Selecting wood/fuel 29
Preparation 29
Storing 29
Moisture 29
Use of the following as fuel is illegal 29
Calorific value of the wood 29

## MAINTAINANCE 30

Sweeping the chimney and cleaning the stove 30
Checking the stove 30
Servicing 30
Combustion chamber lining 30
Gaskets 30
Painted surfaces 30
Removal of baffle plates and combustion chamber lining 31
Cleaning the glass 33
Disposal of stove parts 33

## TROUBLESHOOTING 34

## WARRANTY 36

# TECHNICAL DATA

## INSTALLATION

- All local regulations, including those referring to national and European Standards as well as the information provided in this assembly and instruction manual need to be complied with when installing the appliance
- When you install any kind of fireplace or stove, you must inform the local building and housing authorities. In addition you are obliged to have the installation inspected and approved by a local chimney sweep prior to commissioning
- To ensure best-possible functionality and safety for your installation, we advise you to call a professional fitter. Your Scan Dealer will be able to recommend a qualified fitter in your area. For information on Scan Dealers, please go to www.scan-stoves.com

## SAFETY

Any changes made to the product by the dealer, fitter or user could result in the product and safety functions not functioning as intended. The same applies to the fitting of accessories or extra equipment not supplied by Scan A/S. This could also be the case if parts that are necessary for the operation and safety of the stove are dismantled or removed.



**PLEASE NOTE!**

YOU GET THE BEST USE OF
THE STOVE BY USING
A TOP-DOWN
LIGHTING METHOD

SEE
"INSTRUCTIONS FOR HEATING"



TECHNICAL PARAMETERS FOR SOLID FUEL LOCAL SPACE HEATERS
REG. (EU) 2015/1185, REG. (EU) 2015/1186

| Model identifier(s): Scan 84 Modern Soapstone, Scan 84 Modern Maxi Soapstone | | | | | | |
|---|---|---|---|---|---|---|
| Indirect heating functionality | No | | | | | |
| Direct heat output…(kW) | 5,0 | | | | | |
| Indirect heat output…(kW) | N.A | | | | | |
| **Fuel** | **Preferred fuel** (Only one) | **Model identifier(s)** | **Emissions from space heating at nominal heat output** | | | |
| | | | **PM** | **OGC** | **CO** | **$NO_x$** |
| | | | [X] mg/$Nm_3$ (13 % $O_2$) | | | |
| Wood logs with moisture content ⩽ 25% | Yes | No | 22 | 56 | 979 | 95 |
| Compressed wood with moisture content < 12% | No | No | | | | |
| Other woody biomass | No | No | | | | |
| Anthracite and dry steam coal | No | No | | | | |
| Hard coke | No | No | | | | |
| Low temperature coke | No | No | | | | |
| Bituminous coal | No | No | | | | |
| Lignite briquettes | No | No | | | | |
| Peat briquettes | No | No | | | | |
| Blended fossil fuel briquettes | No | No | | | | |
| Other fossil fuel | No | No | | | | |
| Blended biomass and fossil fuel briquettes | No | No | | | | |
| Other blend of biomass and solid fuel | No | No | | | | |
| **Characteristics when operating with the preferred fuel** | | | | | | |
| Seasonal space heating energy efficiency $\eta_s$ [%] | 71 | | | | | |
| Energy Efficiency Class | A+ | | | | | |
| Energy Efficiency Index (EEI) | 107 | | | | | |

| Item | Symbol | Value | Unit |
|---|---|---|---|
| **Heat output** | | | |
| Nominal heat output | $P_{nom}$ | 5 | kW |
| Minimum heat output (indicative) | $P_{min}$ | N.A. | kW |
| **Auxiliary electricity consumption** | | | |
| At nominal heat output | $el_{max}$ | x,xxx | kW |
| At minimum heat output | $el_{min}$ | x,xxx | kW |
| In standby mode | $el_{SB}$ | x,xxx | kW |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| **Permanent pilot flame power requirement** | | | |
| Pilot flame power requirement (if applicable) | $P_{pilot}$ | N.A. | kW |

| Item | Symbol | Value | Unit |
|---|---|---|---|
| **Use efficiency** (NCV as received) | | | |
| Useful efficiency at nominal heat output | $\eta_{th,nom}$ | 81 | % |
| Useful efficiency at minimum heat output (indicative) | $\eta_{th,min}$ | N.A. | % |
| **Type of heat output/room temperature control** (select one) | | | |
| single stage heat output, no room temperature control | | [yes/no] | |
| two or more manual stages, no room temperature control | | [yes/no] | Yes |
| with mechanic thermostat room temperature control | | [yes/no] | |
| with electronic room temperature control | | [yes/no] | |
| with electronic room temperature control plus day timer | | [yes/no] | |
| with electronic room temperature control plus week timer | | [yes/no] | |
| **Other control options** (multiple selections possible) | | | |
| room temperature control, with presence detection | | [yes/no] | |
| room temperature control, with open window detection | | [yes/no] | |
| with distance control option | | [yes/no] | |
| | | | |
| | | | |

| Contact details | Name and address of the supplier: |
|---|---|

Espen Auensen, R&D Manager, Jøtul AS


| Test in compliance with EN 16510 | | | |
|---|---|---|---|
| | Classification of appliance | Type BF | |
| $P_{nom}$ | Nominel heat output | 5 | kW |
| $N_{nom}$ | Energy efficiency at nominel heat output | 81 | % |
| $N_{s\ nom}$ | Seasonal space heating energy efficiency at nominel heat output | 71 | % |
| EEI | Energy efficiency index | 107 | |
| | Energy efficiency class | A+ | |
| | Fuel | Wood* | |
| | Fuel length, maximum (vertical position) | 350 | mm |
| $M_{h\ nom}$ | Fuel consumption | 1.6 | kg/h |
| | Amount of fuel | 1.3 | kg |
| | Amount of fuel, maximum | 1.9 | kg |
| $CO_{nom}$ | CO emission at 13% $O_2$ at nominel heat output | 0.078<br>979 | %<br>mg/Nm$^3$ |
| $NO_{x\ nom}$ | $NO_x$ emission at 13% $O_2$ at nominel heat output | 95 | mg/Nm$^3$ |
| $OGC_{nom}$ | OGC emission at 13% $O_2$ at nominel heat output | 56 | mg/Nm$^3$ |
| $PM_{nom}$ | Dust emission at 13% $O_2$ at nominel heat output | 22 | mg/Nm$^3$ |
| $p_{nom}$ | Flue draught at nominel heat output | 11 | Pa |
| | Recommended sub-pressure in the connecting piece | 18-20 | Pa |
| | Required combustion air supply | 16.1 | m$^3$/h |
| $T_{fg\ nom}$ | Flue gas temperature at nominal heat output | 236 | °C |
| $T_{s\ nom}$ | Temperature in the flue connecting piece at nominal heat output | 294 | °C |
| T class | Chimney designation | T400 | |
| $Ø_{f.g\ nom}$ | Flue gas mass flow at nominal heat output | 5.6 | g/sec |
| $V_h$ | Standing air loss | 0 | m$^3$/h |
| | Leakage before testing at a gauge pressure of 5 Pa | 0.73 | m$^3$/h |
| | Leakage before testing at a gauge pressure of 10 Pa | 1.59 | m$^3$/h |
| | Leakage before testing at a gauge pressure of 15 Pa | 2.10 | m$^3$/h |
| CON/INT | Continuous operation (CON)/Intermittent operation (INT) | INT** | |
| | Reaction to fire classification | A1 | |

* Use only recommended fuels - designation I.

** Intermittent operation in this context means normal use of a wood-burning stove. In other words, you should let the fire die down until only the embers are left before refueling.

| Basic technical data | | | |
|---|---|---|---|
| | Materials | Stainless steel<br>Cast iron<br>Vermiculite<br>Glass | |
| | Surface treatment | Senotherm | |
| $d_{out1}$ | Connecting piece int. diameter for outside flue pipe | 144 | mm |
| $d_{out2}$ | Connecting piece ext. diameter for outside flue pipe | 148 | mm |
| $d_{out3}$ | Connecting piece int. diameter for inside flue pipe | 157 | mm |
| $d_{out4}$ | Connecting piece ext. diameter for inside flue pipe | 161 | mm |
| | Fresh air connection piece external diameter | 100 | mm |
| L | Overall dimensions (length) | 465 | mm |
| H | Overall dimensions (height) | 1250/1593 | mm |
| W | Overall dimensions (width) | 493 | mm |
| m | Mass (weight) - Scan 84 (Modern/Modern Maxi) | approx. 122/137 | kg |
| $m_{chim}$ | Maximum load of a chimney the stove may carry | 120 | kg |

| Minimum distances to combustible materials (insulated flue pipe) | | | |
|---|---|---|---|
| $d_R$ | Back | 100 | mm |
| $d_S$ | Sides | 450 | mm |
| $d_{S(C)}$ | Sides - corner distance | 100 | mm |
| $d_C$ | Ceiling | 750 | mm |
| $d_P$ | Front | 900 | mm |
| $d_F$ | Front to the bottom front radiation area | 0 | mm |
| $d_L$ | Front to the side front radiation area | 0 | mm |
| $d_B$ | Below the bottom (not regarding feet) | 0 | mm |
| $d_{B1}$ | Bottom edge of door to floor | 350 | mm |
| $d_{non}$ | Minimum distances to non-combustible walls | 50 | mm |




This stove is produced in accordance with type approval for the product, which also covers the product's Assembly and Instruction Manual. Read and follow the user operating instructions carefully.

The Declaration of Performance (DoP) is available from www.scan-stoves.com

## TYPE PLATE

All Scan wood-burning stoves are fitted with a type plate that specifies the approval standards and the distance to flammable materials.

The type plate is located at the rear of the stove.




Type plate

**Scan 84 Modern** CE 25

| | | |
|---|---|---|
| **Standard:** | EN 16510-1:2022, EN 16510-2-1:2022 | |
| **Approved by:** | DTI • NB no. 1235 | |
| **Classification of appliance:** | Type BF | |
| **Use only these recommended fuels:** | Wood logs (I) | |
| **Manufacturer:** | Jøtul AS, POB 1411, N-1602 Fredrikstad, Norway | |
| **DOP:** | 90585600-CPR-20260209 | |
| **Intended use:** | Space heating in residential buildings | |

| | | | |
|---|---|---|---|
| $P_{nom}$ | 5,0 | kW | Read instruction manual for further information |
| $\eta_{nom}$ | 81 | % | |
| $CO_{nom}$ (13% $O_2$) | 979 | mg/m³ | The appliance can be used in a shared flue |
| $NO_{xnom}$ (13% $O_2$) | 95 | mg/m³ | |
| $OGC_{nom}$ (13% $O_2$) | 56 | mg/m³ | |
| $PM_{nom}$ (13% $O_2$) | 22 | mg/m³ | |
| $p_{nom}$ | 11 | Pa | |
| $d_R$ | 100 | mm | The distances apply to stoves with insulated flue pipe |
| $d_S$ | 450 | mm | |
| $d_C$ | 750 | mm | |
| $d_P$ | 900 | mm | |
| $d_F$ | 0 | mm | |
| $d_L$ | 0 | mm | |
| $d_B$ | 0 | mm | |

12067724 90184656-P03

Serial number: **293A1F0004**

1 2 3 4 5 6 7 8 9 10 11 12

## TYPE PLATE EXPLANATION

1. **Type and/or the model number or designation to enable the appliance to be identified**
2. **Applicable standards**
3. **Name of test centre/certification number**
4. **Classification of appliance**
5. **Recommended fuels**
6. **Manufacturer's name and address**
7. **DOP document number**
8. **Table of values:**

   $P_{nom}$ - nominel heat output

   $\eta_{nom}$ - energy efficiency at nominel heat output

   $CO_{nom}$ - CO emission at 13 % $O_2$ at nominel heat output

   $NO_{xnom}$ - $NO_x$ emission at 13 % $O_2$ at nominel heat output

   $OGC_{nom}$ - OGC emission at 13 % $O_2$ at nominel heat output

   $PM_{nom}$ - dust emission at 13 % $O_2$ at nominel heat output

   $p_{nom}$ - flue draught at nominel heat output

   **Minimum distances to combustible material:**

   $d_R$ - back

   $d_S$ - sides

   $d_C$ - ceiling

   $d_P$ - front

   $d_F$ - front to the bottom front radiation area

   $d_L$ - front to the side front radiation area

   $d_B$ - below the bottom (not regarding feet)


9. **CE mark of conformity - The digits indicate the year of issue of the certificate**
10. **Product specifications and instructions**
11. **Type plate number**
12. **Product registration number**

## PRODUCT REGISTRATION NUMBER


All Scan wood-burning stoves are provided with a product registration number. This is unique to your stove and may need to be referred to when you contact Scan A/S or your dealer, e.g. for service or ordering spare parts.

We recommend taking a picture of the type plate and saving it digitally, or writing the number down in a safe place – e.g. together with your housing documents.

Scan 84 (Modern)





Scan 84 (Modern Maxi)






All distances are in mm.
All distances are minimum distances
* Connection of fresh-air intake Ø 100 mm
*** Height to the beginning of flue connecting piece at top outlet

## Minimum distance to flammable materials




## Minimum distance to flammable materials with rotating base (Accessory)





Flammable material

All distances are in mm.
All distances are minimum distances
These distances apply for an insulated flue pipe, all the way down to the stove
For an uninsulated flue pipe, the distance to combustible materials must also comply with the chimney requirements.

**Minimum distance to flammable wall protected by a fire wall**




Flammable material

Fire wall, e.g. 50 mm Jøtul Firewall, 110 mm brick or other material with corresponding fireproof and insulating abilities

All distances are in mm.
All distances are minimum distances
These distances apply for an insulated flue pipe, all the way down to the stove
* Distance to glass

# ASSEMBLY

## TOOLS NEEDED FOR MOUNTING OF THE STOVE

- Spirit level
- Cutting nippers
- Open-end spanner
- 4 mm Allen key

## LOOSE PARTS

In the stoves combustion chamber you will find the following loose parts:

- Connecting piece for inside flue pipe, 6"
- Dekor plate for top plate
- Glove
- Seal for the connecting piece
- Top back plate

## ADDITIONAL ACCESSORIES

- Small shaped floor plate in glass or steel
- Small oval shaped floor plate in glass or steel
- Fresh air adapter for rotating base
- Soap stone top plate for stove with rear or top outlet
- **Scan 84 Maxi** (4 items approx. 40 kg):
  Heat accumulating stones
- Large shaped floor plate in glass or steel
- Rotating base
- Handle - 3 different kinds
- Glass top plate for stove with rear or top outlet
- Cleansing lid

## DISPOSAL OF PACKAGING

Your Scan stove may come supplied with the following packaging:

| | |
|---|---|
| Wood packaging | The wood packaging can be reused and after final use can be incinerated as a $CO_2$ neutral product or sent for recycling. |
| Foam | Send for recycling or waste disposal |
| Plastic bags | Send for recycling or waste disposal |
| Stretch/plastic film | Send for recycling or waste disposal |

## ROOM REQUIREMENTS

The stove must be installed in rooms with a good ventilation. A good ventilation is vital for the efficient operation of your stove.

We recommend installing smoke detectors in the home.

The distances specified in the manual only apply if you comply with the maximum amount of firewood. They only guarantee fire safety.

You should however assess whether furniture or other items might become excessively dry due to being too close to the stove. There is no guarantee that the present building materials can withstand the temperature in relation to visual changes.

- Check that Building Regulations and any local by laws are followed during installation

## FRESH AIR INTAKE

In a well-insulated house, the air used up by the burning process has to be replaced. This particularly applies to houses with mechanical ventilation. There are different ways of making sure that an air exchange takes place. The most important thing is to ensure that there is a supply of air to the room where the wood stove is located. The external wall vent must be located as close to the wood stove as possible, and you must be able to close it when you are not using the wood stove.

National and local building regulations must be followed with regard to the connection of fresh-air intake.

## CLOSED COMBUSTION SYSTEM

You should use the closed combustion system for the wood-burning stove if you live in a newly-built, airtight home. External combustion air is connected through a ventilation pipe via the wall or floor.

We recommend mounting a valve in the ventilation pipe in order to avoid condensate in the stove and the pipe system, when the stove is not in use. It can also be an advantage to insulate the ventilation pipe.

Minimum Ø 100 mm ventilation pipe, maximum length: 6 metres with a maximum of one bend. We recommend smooth steel pipes.

**NOTE: if the stove has a fresh air connexion or closed combustion, the ventilation pipe must be open, when the stove is in use!**






If you want external combustion air via a wall, remove the cover plate at the rear of the stove with a pair of cutting pliers

## EXISTING CHIMNEY AND PRE-FABRICATED ELEMENT CHIMNEY

If you intend to connect your stove to an existing chimney, it makes sense to contact an authorised Scan dealer, or a local chimney sweep, for advice. These experts will also let you know if your chimney needs renovating.

- When connecting a pre-fabricated element chimney, follow the manufacturer's connection instructions for the relevant chimney type

## CONNECTION BETWEEN STOVE AND STEEL CHIMNEY

Your Scan dealer, or local chimney sweep, can advise you on choosing a make and type of steel chimney. This ensures that the chimney will match your wood-burning stove.

## REQUIREMENTS FOR CHIMNEY

The chimney must at least have a T400 designation, with G for the soot fire test. We recommend a chimney with a minimum internal diameter of 148 mm and a length of min. 4 metres.

If you opt to connect the stove with an elbow pipe, you should use a curved elbow, as this gives a better draught.



If you connect the stove with a sharp elbow pipe, the cleansing lid must be placed in the vertical part so that the horizontal part can be cleaned through here.

If the chimney is fitted with a smoke extractor, it must be possible to adjust it to a suitable draft.


The appliance can be installed in a shared flue, if the chimney is dimensioned for it.

The requirements to the chimney and the flue pipe in terms of safety distances must be met.
The chimney shall be proven according to EN 13384-2:2015+A1:2019 depending on the individual situation on site.

- Choosing the wrong length or diameter of chimney could impair functionality
- Always comply exactly with the instructions provided by the chimney supplier

## REQUIREMENTS FOR INSULATED CHIMNEY

The insulation level for insulated chimney: T400-N1-D-Vm-L50050-G100.
The air gap should be 10-15 mm.




## SAFETY DISTANCE

European, national and local regulations concerning safety distances for wood-burning stoves must be complied with.


There are no demands concerning the distance to non-flammable materials, but we recommend a distance of 50 mm in order to facilitate the cleaning of the stove, the flue pipes and the chimney and to prevent possible damages to the wall.

## REMOVAL OF PACKAGING

Check that the stove is not damaged before starting to install it.
The stove comes attached to a wooden pallet on delivery.


1

Screws to be removed



2


Remove the screws and fittings for securing the stove to the pallet




## REMOVAL OF TRANSPORT PROTECTION

Note that the baffle plates are made of porous, ceramic material, and can break. Exercise care when working.


1 Lift the lower baffle plate




2 Turn the baffle plate 90°, and lower it out through the combustion chamber



3 Lift the upper baffle plate and remove protection




4 Mount again the upper baffle plate with the accompanying pin and the lower baffle plate is fitted afterwards




## HEIGHT ADJUSTMENT OF STOVE


The stove has four adjustment screws under the stove. Use the adjustment screws to get the stove to stand straight and level.

**NOTICE: It is very important that the stove is level to allow an optimal function of the door. Please note that once mounted the stove can no longer be adjusted!**


1 Remove the screws for the cover plate in the base



2 Loosen screws slightly and lift off the front of the base



3 Adjust the adjustment screws




## FITTING THE FLUE CONNECTION PIECE IN THE REAR OUTLET

The stove is prepared from the factory for top outlet.

1

Lift the top plate off the stove.


Unscrew the stove's connecting piece and remove it



2

Unscrew the stove's heat shield and remove it.


Using cutting pliers, cut off the cover plate from the rear plate and at its securing points




3

**Important! Only Scan 84 Maxi:**

Using cutting pliers, cut off the cover plate from the rear plate and the heat shield at its securing points




4

Remove the cover.


This is to be used later as a seal and cover at the top of the smoke outlet



## FITTING THE FLUE CONNECTION PIECE IN THE REAR OUTLET

5

Mount the ceramic gasket on the connecting piece



6

Fit the connecting piece with the four screws



7

Fit the cover and tighten it.


Replace the top plate




## SOAPSTONE TOP (ACCESSORY)

You can buy a soapstone top as an accessory. Place steel plate and the soapstone plate on top of the stove.

**Soapstone top for top outlet**



**Soapstone top for rear outlet**



## ROTATING BASE (ACCESSORY)

You can buy a rotating base as an accessory.

See the separate instructions supplied with the rotating base.


*The rotating base cannot be used on models with heat accumulating stones.*




**Rotating base**

## HANDLE (ACCESSORY)

The stove is supplied with a black handle, but you can buy the handle as an accessory in the wood colors below.






Pure natural (Oak) Golden (Oak) Mocca (Oak)

## GLASS TOP (ACCESSORY)

You can buy a glass top plate as an accessory. Place steel plate and the glass plate on top of the stove.



Glass top plate for top outlet



Glass top plate for rear outlet




## HEAT-STORAGE SYSTEM (ACCESSORY)

Heat-storage stones are available for Scan 84 - Modern Maxi.

Heat-storage stones are made from a special material with a high heating capacity. The stones are heated up during the firing and gives off the heat again after the firing, which means that the stove stays warm for a longer time.



**Heat-storage stones**




### TOP OUTLET

The heat conductor plate must always be mounted under the heat accumulating stones.

Mount part 2 (heat conductor plate) and the four stones.

Part 1 (access door) is not to be used.

### REAR OUTLET

Only to be used at rear outlet.

First mount part 1 (access door). Then mount part 2 (heat conductor plate) and the four stones.

The access door is easily removed by means of the butter-fly nut, when the stove has to be cleaned.

## LOAD-BEARING FOUNDATION

All items in our product range come under the category of lightweight fireplaces and stoves and do not normally require any reinforcement of the beam structure. They can be positioned on ordinary beams/floor.

You should of course make sure that the foundation  on which the stove is positioned can indeed support the weight of the stove and, where applicable, a steel chimney, if you have opted for this solution. In case of doubt about the carrying capacity of the floor, please consult a building expert.

## FLOOR PLATE (ACCESSORY)

If you are placing the stove on a flammable floor, you must comply with the national and local regulations on the size of any non-flammable subsurface required to cover the floor around the stove.


Your local Scan dealer can advise you on regulations concerning protection of flammable materials in the vicinity of your stove.

The floor plate's function is to protect the floor and flammable material against any sparks that may occur. A floor plate can be made of steel or glass, but the stove can also be erected on clinker concrete, natural stone or similar materials.


This Scan wood-burning stove has an integrated floor plate at the bottom and can thus be erected directly on flammable material without the need for further protection underneath the stove.



**Small shaped floor plate
in glass or steel
(Suitable for corner installation)**



**Large shaped floor plate
in glass or steel**



**Small oval shaped floor plate
in glass or steel**

# INSTRUCTIONS FOR USE

## CB-TECHNOLOGY (CLEAN BURN)

The stove is equipped with CB technology. In order to ensure optimal combustion of gases released during the combustion process, air passes through a specially developed system of channels. The heated air is conducted into the combustion chamber through the holes in the rear lining of the combustion chamber and at the baffle plates. This airflow is controlled by the rate of combustion and cannot therefore be regulated.

**NOTE: The wood must never be placed higher than the tertiary holes at the rear of the burn chamber (This does not apply at a cold start).**

## PRIMARY AIR

The primary air is used when lighting the stove and must be closed after 10-20 minutes, when the fire has caught well. The primary air can be used continuously when using very hard wood.

**Settings for normal load: 0 - 40%**

## SECONDARY AIR

Secondary air is pre-heated and fed indirectly to the fire. At the same time, the secondary airflow cleans the glass pane to avoid soot build-up. If you over-restrict the secondary airflow, soot can build up on the glass pane. The secondary airflow determines the heat output from your wood stove.

**Settings for normal load: 30 - 70%**

## BAFFLE PLATES

The baffle plates are located in the upper part of the combustion chamber. The plates hold back smoke, making sure it stays inside the combustion chamber for a longer time before escaping through the chimney. This reduces the flue gas temperature as the gases have more time to dissipate heat to the stove.

The baffle plates must be removed for sweeping; see “Maintenance”. Note that the baffle plates are made of porous, ceramic material, and is liable to break easily. You should therefore handle them with care.

*The baffle plates are subject to wear and tear and not covered by the warranty.*


## ASH CONTAINER

Open the door of the stove to access the ash container under the combustion chamber.

**Ash container in closed position**



**Ash container in open position**




- The ash container must always be closed during operation
- The ash container must not be become too full and must therefore be emptied at regular intervals
- Never empty ashes into a flammable container. Ashes can contain glowing embers long after you finish operating the stove

## HANDLE FOR RIDDLING GRATE

The stove is equipped with a riddling grate that - when activated - empties the ashes from the burn chamber into the ash tray.

- The riddling grate must be half open during the firing




Handle for riddling grate

Closed - Open


## INSTRUCTIONS FOR USE

Baffle plates



CB-technique

Handle for riddling grate



Ash drawer

Adjustment of air supply, primary and secondary damper

**SETTINGS FOR NORMAL LOAD:**

| | |
|---|---|
| Primary air: | 0 - 40% |
| Secondary air: | 30 - 70% |

Primary air



Secondary air

0% 100%

# INSTRUCTIONS FOR HEATING

## FIRST HEATING AND PAINT HARDENING

Perform the first heating using a small amount of wood, approximately half of the normal fuel load, and use smaller pieces. Open both the primary and secondary air inlets fully. A slow and gradual heating process helps prevent paint damage and material deformation.

Once the initial fuel has burned down to glowing embers, you can begin the paint-hardening process.

- Load the allowed fuel quantity, again using smaller logs and pieces.
- After this load has burned out, repeat the process 2 to 3 times with the maximum allowed fuel dose, with the primary and secondary air inlets fully open.

  During paint hardening, the product may emit a non-toxic odor. Ensure the room is well ventilated.
  Allow the fire to burn with strong draft until no odor remains.

## ENVIRONMENTALLY-FRIENDLY FIRING

Avoid turning down your woodburning-stove to the point where no flames are visible from the wood, as this leads to poor combustion and low efficiency. The gases released from the wood will not be burnt off due to the low temperature in the combustion chamber. Some of the gases will condense in the stove and flue system as soot, and this could lead to your chimney catching fire at a later point. The residual smoke which exits the chimney will pollute the surrounding area and cause an unpleasant smell.

## LIGHTING

We recommend the use of fire lighters, or similar products. Using fire lighters helps light the wood more quickly and keeps the combustion process clean.

**NOTE: Never use liquid lighting fuels!**

The combustion chamber lining may turn black when the fire is lit.
It will burn clear again the next time wood is added.

**NOTE!**
See our video
about correct firing

## "TOP DOWN" LIGHTING

"Top down" lighting is a more environmentally friendly way of lighting the fire and helps to keep the glass area as clean as possible.

**Do as follows for a correct "top down" lighting:**

- 4 pieces of wood approx. 20 - 25 cm long with a weight of approx. 0.5 - 0.6 kg per piece
- 15-20 thin pieces of firewood of about 20 cm in length, with a total weight of approx. 0.8 - 1.0 kg.
- 3 fire lighters in bag or block form

1. Place the pieces of wood, firewood and fire lighters in the combustion chamber as shown below
2. Set the primary and secondary air controls to maximum in the lighting phase. If the fire is too strong, you may throttle down the primary air damper (at the left)

**NOTE: The wood must never be placed higher than the tertiary holes at the rear of the burn chamber (This does not apply at a cold start).**









## CONTINUOUS OPERATION

It is important to obtain as high a temperature as possible in the combustion chamber. This results in best possible use of the stove and fuel, as well as achieving clean combustion. In this way you will avoid build-up of soot on the combustion chamber lining and glass pane. During operation, you should not see any smoke; just a movement in the air that indicates combustion is in progress.

- After completing the lighting phase, you should have a good layer of embers in the stove; you can then start operation of it properly
- Add two pieces of wood at a time: they should be about 0,4 - 0,6 kg in weight and about 25 cm long

**NOTE: The wood must catch fire quickly. This is why we recommend setting the primary air flow fully open. Operating the stove at too low a temperature and with too little primary air can lead to gases igniting, which can damage the stove.**

- When adding wood, always open the glass door carefully to prevent smoke escaping. Keep the door closed during the whole combustion phase
- Never add wood, while the fire is burning nicely

**At the EN 16510-test the stove was fired as shown on the picture:**

With 2 pieces of birch each 190 mm – with a total weight of 1.3 kg.

Primary air damper 40 % open – secondary air damper 30 % open.

Refuelling interval: 52 min

The criterion for the end of test cycle: 5 % $CO^2$



## WARNING ABOUT OVER-FIRING

If the stove is continiously fired with larger amounts of wood than recommended and/or receives too much air, this can cause a heavy heat development liable to damage both stove and the surrounding walls. We therefore recommend that you always observe the max. recommended amount of fuel (See under "Technical Data").

## USING THE STOVE IN VARIOUS WEATHER CONDITIONS

The way the wind affects the chimney can have a big impact on how your stove reacts under various wind loads; you may need to adjust the airflow to achieve good combustion. Fitting a damper in the flue pipe may also help, as it will allow you to regulate the draught under changing wind loads. The damper must not close more than 80% of the flue pipe.

Fog and mist can also have a big impact on chimney draught; you may need to use other settings for the combustion air to achieve good combustion.

## FIRING IN THE SPRING OR AUTUMN

In the spring/autumn transition period, where there is less need for heating, we recommend you light the stove "top down" once, perhaps adding just two pieces of wood as above to ensure that the combustion chamber lining burns clean again.

## THE FUNCTION OF THE CHIMNEY

The chimney is the wood-burning stove's motor; its performance determines how well your stove will work. The draught in the chimney creates negative pressure in the wood-burning stove. The negative pressure draws the smoke out of the stove and takes in air through the combustion air damper to fuel the combustion process. Combustion air is also used for the air wash system that keeps the window clear of soot.

The draught in the chimney is created by the difference in temperature inside and outside the chimney. The higher temperature difference, the better draught. This is why it is important that the chimney reaches operating temperature before you reduce the damper settings to restrict combustion in the stove (a brickwork chimney will take longer to reach operating temperature than a steel chimney). It is very important that the operating temperature is reached as quickly as possible on days when the draught in the chimney is poor due to unfavorable wind and weather conditions. You need to get a few flames going as quickly as possible. Chop the wood extra thin; use an extra fire lighter etc.

- After longer periods without use, you must check the chimney flue for blockages
- You can connect several units to the same chimney. You should however first check the relevant regulations in this respect

## CHIMNEY FIRE

In the event of a chimney fire, keep the stove door, the ash container, and all dampers on the stove closed. In an emergency, call the fire service.

- We recommend that you get a chimney sweep to check the chimney before using the stove again

## GENERAL NOTES

**PLEASE NOTE! Parts of the wood-burning stove, especially the outer surfaces, become hot during use. Due care should be exercised.**

- Wear a glove when handling the stove
- Never empty ashes into a flammable container. Ashes can contain glowing embers long after you finish operating the stove
- Keep the combustion chamber closed except during ignition, refuelling and removal of residue material to prevent fume spillage
- Keep the air intake and output holes free from any accidental blokage while the stove is in use
- When the stove is not in use you can close the dampers to avoid a draught through the stove
- If the stove has not been used for some time, you should check the flue passageways for potential blockages before relighting
- We advise you strongly not to use the stove over night. The stove is not suited for this purpose

**NOTE: Never place flammable material in the radiation zone of the stove!**

# HANDLING OF THE FUEL

## SELECTING WOOD/FUEL

You can use any type of wood as fuel. However harder woods, such as beech or ash, are generally better for heating, as they burn more evenly and create less ash. Other woods, such as maple, birch and spruce, are excellent alternatives.

## PREPARATION

The best fuel is obtained where the tree has been felled and the wood sawn and split before May 1st. Remember to cut the wood to match the size of the combustion chamber. We recommend a diameter of 6-10 cm. The length should be about 6 cm shorter than that of the combustion chamber to leave enough space for air to circulate. If the diameter of the wood is greater than the above, it should be split down its length. Wood that has been split dries faster.

## STORING

You need to store the sawn and split wood in a dry place for 1-2 years before it will be dry enough to burn. Wood dries faster if you stack it in an airy place. Before using it, it is a good idea to store the wood for a few days at room temperature. Remember that wood absorbs moisture from the air during autumn and winter.

## MOISTURE

To avoid problematic impact on the environment and to ensure optimum operating economy, the wood should be perfectly dry before it can be used as fuel. If you use wood that is too damp, most of the heat it produces will be used up in evaporating the water. The stove will accordingly not increase in temperature, nor emit heat to the room as a result. This is obviously poor economy, and it will cause soot build-up on the glass pane, in the stove and in the chimney. Operation using moist wood also pollutes the environment.

- Maximum wood moisture content should not exceed 20%. A moisture content of 15-18% will deliver best efficiency
- An easy way of checking wood moisture content is to knock the ends of the two pieces of wood together. If the wood is moist, the sound will be slightly muffled
- It is a good idea to take the wood into the house a day before it is to be used

## USE OF THE FOLLOWING AS FUEL IS ILLEGAL

**NOTE: It is absolutely prohibited to fire with painted, pressure impregnated or glued wood, or sea driftwood.**

**NOTE: Never use gasoline, gasoline-type lantern fuel, kerosene, charcoal lighter fluid, ethyl alcohol or similar liquids to start or "reignite" a fire in the stove. Keep all such liquids well away from the stove while it is in use.**

**NOTE: Nor should you ever burn chipboard, plastics, waste or treated paper. These contain substances that are hazardous to human health, to the environment, your stove, and your chimney.**

**In short - make sure you only use proper wood.**

## CALORIFIC VALUE OF THE WOOD

The various woods have different calorific values. In other words, for certain species of wood, you will need to use a greater quantity to achieve the same heating performance. This Instuction Manual assumes that you will be using beach, which has a very high calorific value and is also the easiest wood to get hold on. If you use oak or beech as fuel, you need to bear in mind that these wood types have a greater calorific value than for example birch. To avoid any risk of damage to the stove, you should therefore make sure to use less fuel in these cases.

| Wood types | kg Drywood/m$^3$ | Compared to beech |
|---|---|---|
| Hornbeam | 640 | 110% |
| Beech/Oak | 580 | 100% |
| Ash | 570 | 98% |
| Maple | 540 | 93% |
| Birch | 510 | 88% |
| Pine | 480 | 83% |
| Fir | 390 | 67% |
| Poplar | 380 | 65% |

# MAINTAINANCE

## SWEEPING THE CHIMNEY AND CLEANING THE STOVE

Follow national and local regulations for sweeping the chimney. We recommend having the stove cleaned regularly by a chimney sweep.

Before cleaning the stove and sweeping the flue pipe and chimney, we recommend removing the baffle plates.
(See section "Removal of baffle plates and combustion lining")

**NOTE: All service and reparation must be done, when the stove is cold.**

## CHECKING THE STOVE

Scan A/S recommends that you check your stove thoroughly after sweeping/cleaning. Check all visible surfaces for cracks. Check that all joints are tight and that the gaskets are correctly seated. Worn or deformed gaskets should be replaced.

## SERVICING

We recommend that the stove is thoroughly serviced at least every two years by a qualified fitter. Remember only to use original spare parts.

**The service should include the following:**

- Lubricate hinges using copper grease
- Check the gaskets. Replace any that are broken or have turned hart
- Check the combustion chamber lining and the grate
- Check heat-insulating materials
- Check the locking device

## COMBUSTION CHAMBER LINING

Slight cracks can appear in the combustion chamber lining due to moisture or sudden heating/cooling. These cracks have no influence on the output or lifetime of your stove. However, if the lining starts to crumble and fall out, you must replace it.

*The combustion chamber lining is not covered by the warranty.*

## GASKETS

All wood-burning stoves have seals made of ceramic material fitted to the stove, the door and/or the glass. These seals are subject to wear and tear and must be replaced when necessary.

*Gaskets are not covered by the warranty.*

## PAINTED SURFACES


Clean your wood-burning stove by wiping it down with a dry, lint-free cloth.

If the paint finish gets damaged, you can purchase repair paint in spray form from your Scan dealer. As slight differences in colour shade are possible, we recommend you spray a larger area to achieve a natural blend. For best results, apply repair spray when the stove is warm, but it should preferably not be scalding hot.

**NOTE: Make sure to air the room thoroughly after applying spray paint.**

## REMOVAL OF BAFFLE PLATES AND COMBUSTION CHAMBER LINING


Be very careful when removing the baffle plates from the stove.




Lower baffle plate

Upper baffle plate


Holder for upper baffle plate






Combustion chamber lining

Lift the lower baffle plate 1





Turn the baffle plate 90°, and lower it out through the combustion chamber 2



3


Lift the upper baffle plate and remove the pin






4

Pass the baffle plate edge-first and downwards out through the combustion chamber



5


The baffle plate holder may fall out when the baffle plate is taken out of the stove. See the illustrations below for how to fit it



## REMOVAL OF BAFFLE PLATES AND COMBUSTION CHAMBER LINING

Carefully lift the sides and rear plates of the combustion chamber lining out of the stove

6



## CLEANING THE GLASS

Our wood-burning stoves are designed to prevent serious soot build-up on the glass. The best way to achieve this is to make sure you have a good supply of combustion air. It is also very important that the wood is dry and the chimney correctly dimensioned.

Even if you operate the stove in accordance with our instructions, a slight film of soot may still accumulate on the glass. You can easily remove this film by wiping the glass down with a dry cloth and then with a cloth dampened with glass cleaner.

- Please note that the glass cleaner is not to get into contact with the gaskets, as this can discolour the glass permanently
- The glass cleaner must not come into contact with the painted surfaces, as these can be damaged

## DISPOSAL OF STOVE PARTS

| | |
|---|---|
| Steel/cast iron | Send for recycling |
| Glass | Dispose of as ceramic waste |
| Combustion chamber lining | Vermiculite and chamotte are not recyclable. Dispose of as waste. |
| Baffle plate | Vermiculite is not recyclable. Dispose of as waste. |
| Gaskets | Dispose of as waste |

# TROUBLESHOOTING

## SMOKE ESCAPING

- Damp wood
- Chimney is not properly dimensioned for the stove
- Is the chimney the right height for its surroundings?
- At rear outlet, check that the flue pipe does not obstruct the chimney draught
- Chimney not drawing properly
- Check if the smoke gas pipe/chimney are blocked
- Vacuum in room
- The door is opened before the embers have burned down sufficiently

## WOOD BURNING TOO QUICKLY

- The air valves are set incorrectly
- Inferior firewood (waste wood, pallets etc.)
- The baffle plates is incorrectly mounted or missing
- Chimney too large

## SOOT BUILD-UP ON GLASS

- Incorrect secondary airflow setting
- Damp wood
- Inferior firewood (waste wood, pallets etc.)
- Vacuum in room
- Excessive primary air
- Wood pieces too large on lighting
- Chimney not drawing sufficiently

## WHITE SHADOW ON THE INSIDE OF THE GLASS

- Over-firing (See "Instructions for heating")
- Vacuum in the room
- Too much primary air

## EXCESSIVE SOOT BUILD-UP IN CHIMNEY

- Poor burning (more air required)
- Damp wood

## THE SURFACE OF THE STOVE IS TURNING GREY

- Overheating (see instructions for heating)

## POOR HEATING PERFORMANCE OF STOVE

- Damp wood
- Inferior wood quality with low fuel value
- Not enough wood
- Baffle plates are not fitted correctly


## SMELL AND SOUND OF THE STOVE

- The lacquer on the stove hardens when you use the stove for the first time; this can cause an odour. Open a window or a door for ventilation, and make sure the stove is heated up sufficiently to avoid odours later
- When heating up and cooling down, the stove may make some clicking noises. These are due to the huge temperature differences to which the material is exposed and do not indicate any product defects

## THE DOOR DOES NOT CLOSE

It may occur during transport that the locking device moves out if its correct position, so that the door does not close properly. This can easily be adjusted.


1 Remove the cover plate



2 Press the locking device in its correct position



3




4 Mount the cover plate



Over time, the door may “hang” a little.
You can correct this by pressing the locking device upwards by means of an adjustable spanner.



# WARRANTY

All wood-fired Scan products are made of high-quality materials and subject to strict quality controls before leaving the factory. We give a warranty of 5 years on manufacturing errors or defects.

You must quote your stove's product registration number when you contact us or your authorized Scan dealer with a warranty claim.

The warranty covers all parts which in the opinion of Scan A/S require repair or replacement due to manufacturing or construction error

The warranty applies to the original purchaser of the product only, and is not transferable (except on prior sale).

The warranty covers only damage caused by manufacturing or construction errors.

## THE FOLLOWING PARTS ARE NOT COVERED BY THE WARRANTY

- Wear and tear parts, such as the combustion chamber liners, baffle plates, riddling grate, glass, and seals (except for defects which were present on delivery)
- Defects caused by external chemical and physical influences during transportation, storage and assembly, or at a later time.
- Soot build-up caused by poor chimney draught, damp wood, or improper use
- Costs of additional heating in connection with a repair
- Transport costs
- Costs for setting up, removing the wood stove

## THIS WARRANTY IS VOID

- In case of incorrect installation (the installer is responsible for observing and complying with legal requirements and local bylaws, along with this Instructions manual for the wood-burning stove and accessories)
- In case of improper use, and/or use of prohibited fuels, non-original spares (see this instructions manual)
- If the product registration number of the stove has been removed or damaged
- In case of repairs that do not comply with our instructions or instructions by an authorized Scan dealer
- In case of any manipulation of the original state of this Scan product or its accessories. Any unauthorized modification of the stove may not be carried out
- This warranty is only valid in the country to which this Scan product was originally supplied

Always use original replacement parts, or parts recommended by the manufacturer.

# NOTES

Product registration number

Quote this number at all enquiries

Edition:
EU 90184500-P08

16.11.2026

Jøtul AS | Postboks 1411 | 1602 Fredrikstad, Norway | www.scan-stoves.com